

REMOTE BOTTLE OPENER PN 11107

Congratulations on purchasing the worlds' first and finest remote bottle opener. This opener will allow you to stay in the comfort of your seat and open your nitrous bottle. Nitrous Express has designed the opener to work with NX bottles, but may be adapted to fit all other bottles valves.

The motor has been installed on the main body for your convenience. The motor can be rotated to 4 different positions if clearance is needed.

1. Remove the bottle from the vehicle, leaving the nut and nipple intact.. Install the furnished -4 cap onto the nipple. Open the valve completely. This will give the proper installation height for the opener to work without binding.
2. Using a ½ wrench remove the hand wheel from the top of the bottle valve.
3. Install the adaptor collar around the top of the bottle valve just below the hand wheel. (See Illustration A.)
2. Install the valve opener gear over the square brass stem on the top of valve. (See Illustration A)
5. Slide the t-bolt clamp over main body; do not tighten the clamp at this time. (See Illustration B.)
6. Install the main body over valve and collar making sure the gear on the drive motor meshes with the bottle gear correctly. NOTE: If the gears do not mesh correctly the main body will not set down properly and damage to the drive motor transmission is possible.
7. Once the main body is installed correctly, tighten the t-bolt clamp securely.
8. Wiring your system. (See Illustration C.) Cut the red and black wires 10 inches from the motor. Install the seals and male weather pack terminals on the motor side wires. The wires going to the activation switch will use female terminal ends. Slide the terminals into the weather pack housings. NOTE: CARE MUST BE TAKEN TO INSTALL THE TERMINALS WITH THE CORRECT WEATHER PACK HOUSING. IMPROPER INSTALLATION WILL NOT ALLOW THE TWO HALVES TO PUSH TOGETHER.
9. Run the remaining red and black wire to the opener switch mounting location. Follow the switch socket diagram for proper location of these

wires.

10. Route the 12ga. red wire to an ignition switch controlled 12-volt source. The blue wire will go to ground. (See Illustration D.)
11. The switch has an internal light for easy location a night. This lighting terminal will connect to an interior lighting wire for proper dimming function to work. To locate this power source consult a wiring manual for your vehicle. (See Illustration D.)



Illustration A



Illustration B



12. Now to complete the installation reinstall the bottle, and plug the weather pack connectors together. Turn the vehicle on and press the close side of the opener control switch for 2 seconds and the opener should completely close the bottle valve. Slowly remove the D-4 cap on the bottle nipple. A small amount of nitrous will escape, if the valve is leaking reinstall the cap and cycle the opener open and closed and recheck for leaks. If the opener does not completely close the valve a clutch adjustment may be necessary. See the illustrations below for proper clutch adjustment. After the valve has been verified not to leak reinstall the supply line. The installation is now complete and the remote opener is ready to use.





Illustration D




Illustration E