

# Jetting for RZR 900 and 1000 Plate System

Do not use platinum tip, extended tip or any spark plug with multiple ground straps or split ground straps. When in doubt about heat range always go one step colder.



Use this jetting ONLY IF USING A 15005P FUEL PUMP!!!!

RZR 900 and 1000 plate

HP	N2O jet	Fuel jet
30	16	14
50	22	19
80	28	24
100	34	30
125	38	34
150	46	48

Use this jetting ONLY IF YOU TIE INTO THE FACTORY FUEL SYSTEM RUNNINGS AT 45-55PSI FUEL PRESSURE!!!!

RZR 900 and 1000 plate

HP	N2O jet	Fuel jet
20	12	9
30	16	10
40	22	12