
To Ground
To 12v(+)
Blue wire of opener
Black wire of opener
To Ground
To 12v(+)
Black from LED run to ground
To Bottle Heater Relay Trigger
To 12v(+)
Not Used
Red wire of LED to resistor then to postive side of relay trigger wires
(Diode must be used in line with the power to the LED)
To N2O system Relay Trigger
To 12v(+)
To postive side of Purge solenoid
To 12v(+)
Black from LED run to ground